

THE NEW SONDERHOFF RINSING WATER RECYCLING SYSTEM FOR SUSTAINABLE MIXING HEAD CLEANING



THE NEW SONDERHOFF RINSING WATER RECYCLING SYSTEM FOR SUSTAINABLE MIXING HEAD CLEANING

Sustainability is a crucial part of Henkel's corporate strategy. For this reason, attention is paid to offering our customers sustainable solutions not only in the development of adhesives and sealants, but also in the development of mixing and dispensing machines.

Sonderhoff mixing and dispensing machines are sustainable because they use FIPFG technology to apply only as much material as necessary. In addition, the mixing chamber is cleaned of material build-up using an **ecological high-pressure water rinsing system**. Compared to conventional solvent rinsing, only tap water is used. Solvents, on the other hand, are not ecologically degradable and cause costs for additional purchases and disposal.

With the newly developed **rinsing water recycling system**, the rinse/process water for high-pressure water rinsing is cleaned in a two-stage filtering process. The filtered rinse water is then available as process water for several further rinsing cycles.

This significantly reduces the freshwater consumption of the high-pressure water rinsing system as well as the amount of water that needs to be disposed chargeable to the sewage system.

The rinsing water recycling system unit is set up in the traversing area of the mixing head of the dosing machine and can be retrofitted and connected by the user for the mixing and dosing systems with the linear robots LR-HD, LR-HE plus or 6-axis robots at any time as an option (this does not apply to the 3E and SMART systems).

The cost savings achieved by using the rinsing water recycling system enable the investment costs to be amortized after a few years and therefore a return on investment.



The process sequence of the rinsing water recycling system

The mixing chamber in the mixing head of the DM 50x dosing machine is cleaned using ecological high-pressure water rinsing, which uses approx. 2 x 200 ml of tap water per cleaning cycle, depending on the size of the mixing chamber and the material used. This is done by injecting water into the mixing chamber at an adjustable high pressure of between 80 and 140 bar, so that the surfaces in the mixing chamber are mechanically cleaned of material build-up.

The process sequence of the rinse water recycling system for cleaning the process water for high-pressure water rinsing begins with filling the 25 litres **process water tank (1)** with tap water plus glycol 4 %. From there, the water is drawn in and the water used for this high-pressure cleaning is supplied to the mixing chamber via a hose.

The rinsing water used for this high-pressure cleaning is dispensed through the mixing head nozzle into the **rinsing water tank (2)**. There, coarse impurities from the rinsing process of the mixing chamber are passed through a **50 µm coarse filter (3)** in the first filter stage and filtered out.

When the water level in the rinse water tank (2) reaches a certain level after several rinsing processes, the roller lever valve is triggered by the integrated float and the pneumatic **diaphragm pump (4)** is activated.

The rinse water is then cleaned again by the second filter stage with a 5 µm **fine filter cartridge (5)** and pumped back into the process water tank (1).

The filtered process water is thus available for several further rinsing cycles. Depending on the number of rinsing cycles the 25 litres of fresh water in the rinsing water recycling system must be changed approximately every 2 months.

If the water level in the process water tank (1) falls below a minimum level, a warning is issued via a visual and acoustic display.

1: Process water tank

2: Rinse water tank

Filling shot container

3: Coarse filter

Hose line with ball valve and connections from the rinse water tank to the diaphragm pump

5: Fine filter cartridge

Maintenance unit

with air connection, manual switchon and filter control valveand pressure gauge

4: Diaphragm pump

with lockable pressure control valve

Hose line

with ball valve, sieve filter and connections from the service water tank to the high-pressure water rinsing of the dosing machine





1: Process water tank

The process begins with filling of the 25 litres process water tank. From there, the water is sucked in and is supplied via a hose for the high-pressure water rinsing of the mixing chamber in the mixing head. If the water level in the process water tank falls below a minimum level, the float (B) activates the roller lever valve (A) and an audible and visual signal is emitted.



7: Process water tank

The finely filtered rinse water is pumped back into the **process water tank** as purified process water, where it is available for several more rinse cycles.



6: Fine filter cartridge

The coarsely filtered rinsing water, activated by the membrane pump, is fed to the second filter stage and purified there with a **5 µm fine filter cartridge**.




2: High-pressure water rinsing

with ecological high-pressure water rinsing (HDW), the mixing chamber in the mixing head is cleaned by injecting (approx. 2 x 200 ml per cleaning cycle, depending on the size of the mixing chamber and the material used) at an adjustable high pressure. material used) at an adjustable high pressure of between 80-140 bar.




3: Rising water tank

The rinsing water used for high-pressure cleaning is dispensed through the mixing head nozzle into the rinse water tank.




4: Grobfilter

Coarse impurities from the rinsing process in the mixing chamber are passed through a **50 µm coarse filter** in the rinsing water tank in the first filter stage and filtered out.



5: Diaphragm pump

When the water level in the rinse water tank reaches a certain level after several rinsing processes, the roller lever valve is triggered by the integrated float and the pneumatic diaphragm pump is activated.



Cost saving when using the Rinsing Water Recycling System

Initial situation for the customer's work process:

Working days per year (5 days per week)	253	
Shifts per day	2	
Rinsing cycles per shift	20	
Water per rinse cycle	400	ml
Disposal costs per tonne	800	€

	without rinsing water recycling system		with rinsing water recycling system	
Water consumption / year	4.048	L	120	L
Disposal costs for contaminated water (litres) / year	3.200	€		
Disposal costs for contaminated water, filter + filter cake / year			96,00	€
Costs per fresh water litre / year	12,15	€	0,36	€
Labour costs / year	675	€	180	€
Filter and glycol additive purchase			60	€
Total	3.887,15	€	336,36	€
Savings / year (Y)			3.550,79	€/Y



FAQ RINSING WATER RECYCLING SYSTEM

1. What is the maximum distance between the rinsing water recycling system and the high-pressure water rinsing?

The maximum hose length: 10 m

2. Which robots does the rinsing water recycling system work with?

6-axis robot, 3-axis linear robots LR-HD, LR-HE pluss

3. Can the rinsing water recycling system communicate with our dosing machines or be controlled by them?

No, it is a stand-alone version without sensors or PLC connections.

4. For which chemicals can the rinsing water recycling system be used?

With all adhesives and sealants that are not liquid after dosing or water-soluble (filter then does not work).

5. How must the rinsing water recycling system be set up?

The rinsing water recycling system replaces the previous rinsing and fill shot station and must be positioned so that the rinsing and fill shot positions of the rinsing water recycling system are aligned in the same way (see layout in the operating instructions).

6. Can the rinsing water recycling system be retrofitted to existing dosing machines?

Yes, usually for the mixing and dosing systems with 3-axis linear robots LR-HD, LR-HE plus or 6-axis robots (this does not apply to the 3E and SMART systems), provided the existing system layout offers sufficient space.

7. What kind of connections does the rinsing water recycling system need?

A connection hose is only required for compressed air (max. 8 bar) and for water from the process water tank to the HDW rinsing of the dosing system (see flow diagram in the manual).

8. How often need the filters to be changed?

We recommend checking the coarse filter once a week. Depending on the frequency of rinsing shots, the coarse filter and the fine filter should be changed once a month on average. The rinse water and the 5µm fine filter should be changed every 2-4 months, depending on the number of rinses, and the rinse and process water tank should be cleaned.

9. How often does fresh water need to be topped up?

We recommend checking the water level in both tanks once a week. If the water level in the process water tank is less than half the fill level and there is hardly any water left in the rinse water tank, water must be topped up. If the rinse water tank is almost empty, the process water tank can be filled up to the maximum level mark.

10. Under what conditions can the rinsing water recycling system not be used?

- A: The chemicals used are water-soluble
- B: Chemistry used is liquid after the rinse cycle
- C: Dosing machine in 3E cell or Smart cell
- D: HDW positioning at head height or above (suction capacity of the HDW is then insufficient)

11. Is the rinsing water recycling system height-adjustable?

The rinsing water recycling system itself is not height-adjustable, but the injection nozzle can be pulled out by max. 100 mm using a knurled screw, to facilitate alignment with the mixing head. If this is not sufficient, the rinsing water recycling system would have to be placed on a pedestal.

12. Is the rinsing water recycling system mobile?

No, once it has been positioned, it should be fixed to the floor with heavy-duty anchors.

13. Does the water in the rinsing water recycling system have to be changed?

Yes, despite the addition of glycol, algae may form in the water due to impurities or it may otherwise 'go bad'. It is therefore advisable to change the water in the entire system 3-4 times a year so that the fine filter does not become clogged.

14. How do you recognize when there is not enough water in the process water tank?

The visual and audible indicators of the signal when there is not enough water in the process water tank. The visual signal turns red, and the acoustic indicator emits a whistling sound.

15. Can the volume of the acoustic signal for the process water tank be changed?

Yes, the volume can be adjusted using the throttle located near the acoustic signal.

Customer-specific solutions – worldwide and for many industries

The Henkel specialists for the Sonderhoff portfolio
are available globally

KOLO, POLAND

External Subcontracting Location

DÜSSELDORF, GERMANY

Center of Expertise

ELGIN, ILLINOIS, USA

Regional Hub

RICHMOND (KANSAS CITY), USA

Regional Hub

DORNBIRN, AUSTRIA

Center of Expertise

BARCELONA, SPAIN

External Subcontracting Location

OGGIONO, ITALY

Regional Hub

INCHEON, KOREA

External Subcontracting Location

SHANGHAI, CHINA

Regional Hub

PUNE, INDIA

Regional Hub

PUNE, INDIA

External Subcontracting Location

SÃO PAULO, BRAZIL

External Subcontracting Location

Global presence



Every year, more than 300 million seals are manufactured in more than 50 countries using products from Henkel's Sonderhoff portfolio. At our Centers of Expertise and Regional Hubs, our specialists offer application engineering advice, e.g. selecting a suitable material system and sampling of your components, as well as project management for dosing systems and automation. You will receive training from us on how to use the FIPFG technology and we will support you with the selection of spare parts and a regular service offering. Furthermore, we will be pleased to take over parts of your production for you – from small to large series – at our subcontracting locations.

Sales staff at all other Henkel locations worldwide will also be happy to answer any questions and provide you with further information on our sealing, bonding, and potting solutions. We look forward to hearing from you.



Henkel AG & Co. KGaA

Henkelstraße 67
40589 Düsseldorf
Germany
Tel.: +49 211 797-0
Fax: +49 211 798 4008

www.henkel.com
www.sonderhoff.com

Get in contact with us



The description of the possible fields of use of our products as well as the technical data and values only have a general character and do not mean that a certain product can be used under all conditions in the respective field of use. In this respect, the stated field of use is not a binding specification or usage provision. Due to the great number of environment variables and their influences (e.g. temperature, test specimens, size, interaction with substrates, influence of machines, or the like) you as our customer must check whether the product is suitable for your specific field of use. We will be pleased to assist and advise you in this respect. Except as otherwise noted, all marks used above are trademarks and/or registered trademarks of Henkel and its affiliates in the U.S., Germany and elsewhere.

© 11.2024 Henkel AG & Co. KGaA. All rights reserved